

# USER MANUAL

## M9B

### Stereo Wireless Sports Earphones

---

Please read this manual in its entirety to ensure best fit and sound.



# PACKAGE CONTENTS

## M9B

Stereo Wireless  
Earphones

---



**M9B**  
Stereo Wireless  
Earphones



Micro-USB  
charging  
cable




Eartips  
(4 pairs)



User  
manual

## PRODUCT OVERVIEW



# M9B

Stereo Wireless  
Earphones

---

### Earpieces

- 1 Right earpiece
- 2 Left earpiece

### Remote

- 3 Microphone
- 4 LED status indicator light
- 5 Volume up/next track button
- 6 Multifunction button
- 7 Volume down/previous track button
- 8 Micro-USB charging port

## CHARGING

Connect the charging cable to any powered USB port and to the charging port located on the headset's remote control.

The status indicator light will stay red while charging and turn blue when fully charged.

When the battery is low, the headset will say "battery low" and a red light on the remote will flash twice every two seconds.

Apple® devices such as the iPhone®, iPad®, and iPod touch® will also display an on-screen headset battery indicator when the M9B is connected.



Note: the lifetime of the battery will be significantly reduced if your headset is not charged for a long period of time. It is recommended to charge your headset at least once a month.

## WEARING THE EARPHONES

Wearing the M9B correctly will ensure the most comfortable and secure fit

### STEP 1:

Select and install the correct eartips.

The M9B is an in-ear headphone and relies on a tight seal between eartip and ear canal to deliver great sound and bass.

Four sizes of ear tips are included to help you achieve the best fit.

We recommend trying all of them and selecting the ones with the best sound and comfort for your ears.



continued on next page

## WEARING THE EARPHONES (Cont.)

### STEP 2:


Put the earphones in your ears. Adjust the earpieces for an airtight seal.



When worn correctly, the earphones will reduce outside noise and deliver good bass impact. If you do not get much bass or hear tinny sound with excessive treble presence, re-adjust the fit of the earphones in your ears and/or try a different size of eartips.

### STEP 3 (Optional):

Adjust the cable cinch to reduce cable slack for a more secure and comfortable fit.



# BLUETOOTH PAIRING

Your headset must be paired to a Bluetooth device before it can be used. It is only necessary to pair your headset once with each device.

1. Make sure the M9B is turned off and within 3 feet (1 meter) of the device you wish to pair. Press and hold the Multifunction button for about 4 seconds until the headset says "Pairing". The status indicator light will flash red and blue in an alternating pattern while the M9B is in pairing mode.

Note: The M9B will remain in pairing mode for 5 minutes or until paired.

2. Open the Bluetooth menu on the device you wish to pair.

## iPhone, iPad, and iPod touch

- a) On your device, open the **Settings** menu
- b) Select **Bluetooth**. If Bluetooth is not on, turn it on. The iPhone/iPad/iPod® will automatically search for new devices

## Android™ Phones and Tablets

- a) On your device, open the **Settings** menu
- b) Select **Bluetooth** (on older Android devices **Bluetooth** is found in the **Wireless & Networks** menu). If Bluetooth is not on, turn it on. Select "Search for Devices" or "Refresh" if your phone or tablet does not automatically search for new devices.

continued on next page

## BLUETOOTH PAIRING (Cont.)

### Windows® Phone 8 devices

- a) On your device, open the **Settings** menu
- b) Select **Bluetooth**. If Bluetooth is not on, turn it on. Windows Phone 8 will automatically search for new devices

### Computers, Laptops, and Other Devices

Visit [www.MEEaudio.com/Bluetooth](http://www.MEEaudio.com/Bluetooth) for pairing and setup information.

3. Wait until you see "M9B" on the screen of your device.
4. Select "M9B" on your device and follow any further prompts to pair. Use "0000" if a pin is required. Once connected, the headset will say "Connected" and the blue indicator light will flash three times every 9 seconds.

If pairing fails after several tries, please refer to your device's user manual for additional information.

Visit [www.MEEaudio.com/Bluetooth](http://www.MEEaudio.com/Bluetooth) for instructional pairing videos and troubleshooting information.



## CONNECTING TO PAIRED DEVICES

When turned on, the M9B will automatically connect with the last paired and/or connected Bluetooth device that is powered on and within range. If the headset does not connect automatically, open the Bluetooth menu on your device and select "M9B" from the list of paired devices.

## MULTIPOINT

Multipoint allows two Bluetooth devices to be connected to the M9B simultaneously. Both devices will need to be paired before multipoint can be used by following the pairing procedure described in the **Bluetooth Pairing** section for each device.

To use two Bluetooth devices with the M9B, turn the unit on and wait until it connects to the last paired device. Then, select "M9B" from the Bluetooth menu of second device you wish to connect. The headset cannot be connected with more than two devices.

To switch between the two devices, pause audio playback on the active device and start audio playback on the other connected device. It takes several seconds for the audio to switch.

Incoming calls will always take precedence over media. When a call comes in, the M9B will automatically activate the device with the incoming call. Some devices, such as computers and standalone audio transmitters, do not allow audio switching except when a phone call occurs.

If you no longer wish to connect to multiple devices, disable Bluetooth on the device you do not want connected to the M9B or remove the "M9B" pairing from the Bluetooth menu of that device.

## FUNCTIONALITY & CONTROLS

Headset Status	Function	Operation
Powered off	Power on	Press and hold the <b>Multifunction button</b> for 3 seconds
Powered on	Power off	Press and hold the <b>Multifunction button</b> for 3 seconds
	Raise or lower volume	Press the <b>Volume up</b> or <b>Volume down</b> button . Headset will produce a tone when maximum or minimum volume is reached.
Media playing	Play/pause media*	Press the <b>Multifunction button</b>
	Next track	Press and hold the <b>Volume up</b> button for 1 second
	Previous track	Press and hold the <b>Volume down</b> button for 1 second
Incoming phone call	Answer phone call	Press the <b>Multifunction button</b>
	Reject phone call	Press and hold the <b>Multifunction button</b> for 2 seconds
Phone call in progress	End phone call	Press the <b>Multifunction button</b>
	Mute/unmute microphone	Press and hold the <b>Volume down</b> button for 2 seconds to mute. Repeat to unmute. Headset will produce two tones when muted or unmuted.

continued on next page

## FUNCTIONALITY & CONTROLS (Cont.)

Headset Status	Function	Operation
Call in progress, second incoming call	End current call and answer new call	Press the <b>Multifunction button</b>
	Answer new phone call, put current call on hold	Double press the <b>Multifunction button</b>
	Reject new call	Press and hold the <b>Volume up</b> and <b>Volume down</b> buttons at the same time for 1 second
One call active, one on hold	End current call and switch to call on hold	Press the <b>Multifunction button</b>
	Switch active call	Double press the <b>Multifunction button</b>
No phone calls in progress	Redial**	Double press the <b>Multifunction button</b>
	Activate Siri® / voice command**	Press and hold the <b>Multifunction button</b> for 2 seconds. Repeat to cancel.

\* You may need to bring your media player up on the screen for initial playback to start

\*\* Not all devices/applications support this functionality.

## FACTORY RESET

A factory reset will clear all paired devices from memory. To perform a factory reset, put the headset in pairing mode as described in the **Bluetooth Pairing** section, then press and hold the **Volume up** and **Volume down** buttons at the same time for 2 seconds. The headset will produce three tones and the blue indicator light will flash twice to indicate the memory has been cleared. The headset will need to be paired with a Bluetooth device before use.

## SAFETY AND CARE

- To clean, remove the eartips and rinse them under running water. Clean the earphones using a cotton swab damp with a small amount of rubbing alcohol. Allow the earphones and eartips to dry completely before resuming use.
- Use only the supplied Micro-USB charging cable or a compatible replacement from a reputable manufacturer.
- Battery performance will be severely decreased when stored in extreme temperatures: below  $-10^{\circ}\text{C}/14^{\circ}\text{F}$  or above  $50^{\circ}\text{C}/122^{\circ}\text{F}$ , including direct sunlight.
- If the device comes in contact with liquids, quickly wipe away. If submersed in water, do not turn the device on until completely dried. Note: liquid submersion voids the warranty.
- Do not use around flammable gasses as fire may occur.
- Keep the device and packaging out of reach of children.

## WARNING

Using headphones at high volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety. Turn the volume all the way down after connecting your earphones, then gradually increase the volume until you reach a comfortable listening level. Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.

## TROUBLESHOOTING

Visit [www.MEEaudio.com/Bluetooth](http://www.MEEaudio.com/Bluetooth) for troubleshooting procedures.

## SPECIFICATIONS

Visit [www.MEEaudio.com/M9B](http://www.MEEaudio.com/M9B) for product specifications.

## WARRANTY

The M9B is covered by a 1-year manufacturer warranty. For more information, visit [www.MEEaudio.com/Support](http://www.MEEaudio.com/Support).

Have a question?

Email [support@MEEaudio.com](mailto:support@MEEaudio.com)



---

MEE audio and its logo are registered trademarks of S2E, Inc. All rights reserved.

iPhone®, iPad®, iPod®, iPod touch®, and Siri® are registered trademarks of Apple Inc.

Android™ is a registered trademark of Google Inc.

Windows® Phone is a registered trademark of Microsoft Corporation in the United States and other countries.



[www.MEEaudio.com](http://www.MEEaudio.com)  
[support@MEEaudio.com](mailto:support@MEEaudio.com)