

NEVER LOSE FOCUS



SECURE-FIT STEREO BLUETOOTH WIRELESS SPORTS IN-EAR HEADPHONES

www.MEEaudio.com/X8

Model: X8

SPORTS EARPHONES FIT GUIDE

Please visit the Sports Earphone Fit Guide at www.MEEaudio.com/Fit for easy-to-follow video guides to ensure the best fit, comfort and sound.



PACKAGE CONTENTS



X8 Stereo Bluetooth Wireless Sports In-Ear Headphones



Micro-USB charging cable



Carrying




4 pairs of eartips



User

PRODUCT OVERVIEW



REMOTE

- Volume Up / Skip Track Button (+)
- 4. Volume Down / Previous Track Button (-) 5. Status Indicator Light
- 2. Multifunction Button (M)

3. Microphone

6. Micro-USB Charging Port

CHARGING

Connect the charging cable to any powered USB port and to the charging port located on the headset's remote control. Charge time is approximately 2 hours. The status indicator light will stay red while charging and turn blue when fully charged.

Note: For maximum sweat resistance, make sure that the USB port cover is closed completely after charging the headset.

When the battery is low, the headset will say "battery low" and a red light on the remote will flash periodically.

Apple® devices such as the iPhone®, iPad®, and iPod touch® will also display an on-screen headset battery indicator while the X8 is connected.




WEARING THE EARPHONES

STEP 1: SELECT AND INSTALL THE CORRECT FARTIPS.

The X8 is an in-ear headphone and relies on a tight seal between the eartips and your ear canals to deliver good bass response and overall sound quality. Four sizes of eartips are included to help you achieve the best fit. We recommend trying all of included eartips and selecting the ones that provide the best sound and comfort for your ears.

Choose eartips that:

- · Allow the earphone to fit flush in your ear
- Seal with your ear canal and reduce outside noise when inserted
 - · Provide the best bass response



Install eartips as shown. Make sure eartips are installed securely before use.

WEARING THE EARPHONES (CONT.)

STEP 2: INSERT INTO EARS

The X8 earphones feature an over-the-ear design with Flex-wire earhooks.

To put on the X8, first identify the left and right earpieces as indicated by the "L" and "R" markings. They are not interchangeable.




Place the cable behind your neck, route the earhooks around your ears, and put the earpieces in your ears. Adjust each earpiece until it fits flush in the ear and the earlip seals in the ear canal.



WEARING THE EARPHONES (CONT.)

STEP 3 (OPTIONAL): TIGHTEN CABLE CINCH

Adjust the cable cinch to reduce cable slack for a more secure and comfortable fit while exercising, jogging, or performing other physical activity.



WEARING THE EARPHONES (CONT.)

CORRECT FIT

The earphone sits flush in the ear and the cable is secure behind the ear.

When worn correctly, the earphones will reduce outside noise and deliver good bass impact.



If you do not get much bass or hear tinny sound with excessive treble presence, re-adjust the fit of the earphones in your ears and/or try a different size of eartips.

Note: If you must remove and reinsert the earphones while working out, avoid getting sweat in the nozzle as this may lead to a temporary reduction/loss of sound.

(OPTIONAL) IMPROVING PHONE CALL PERFORMANCE

For best microphone performance during phone calls, the X8 can be worn with the wire in the front to improve microphone positioning. Orient the microphone towards your mouth to ensure the clearest and loudest voice pickup.



BLUFTOOTH PAIRING

Your headset must be paired to a Bluetooth device before it can be used. It is only necessary to pair your headset once with each device.

Make sure the X8 is turned off and within 3 feet (1 meter) of your device. Put the headset in pairing mode by holding the Multifunction button for about 5 seconds until the status indicator light begins to flash red and blue in an alternating pattern and the headphone says "Pairinc".

Phones and tablets

Open the Settings menu and select Bluetooth. If Bluetooth is not on, turn it on. Select "Search for Devices" or "Refresh" if your phone or tablet does not automatically search for new devices.

Other devices

Visit www.MEEaudio.com/Bluetooth for pairing & setup information.

Wait until you see "MEE audio X8" on the screen of your device. Select it and follow any further prompts to pair. Use "0000" if a pin is required. Once connected, the headset will say "Connected" and the blue indicator light will flash two times every 3 seconds.

If pairing fails, please refer to your device's user manual for further information. Visit the Bluetooth Support Page at www.MEEaudio.com/Bluetooth for instructional pairing videos and troubleshooting information.

CONNECTING TO PAIRED DEVICES

When powered on, the X8 will automatically connect with the most recently paired and/or connected Bluetooth device that is powered on and within range. If the headset does not connect automatically, open the Bluetooth menu on your device and select "MEE audio X8" from the Bluetooth device list.

CONNECTING TO MORE THAN ONE DEVICE (MULTIPOINT)

Multipoint is a feature that allows two Bluetooth devices to be connected to the X8 simultaneously. To use two Bluetooth devices with the X8, first pair each one by following the pairing procedure described in the BLUETOOTH PAIRING section and then power the headset off. When powered on again, the headset will connect to the 2 most recently-paired devices, as long as they have Bluetooth enabled and are within range. If a device that has already been paired does not connect automatically, select "MEE audio X8" from the Bluetooth menu of the device.

Note: Headset operating range and battery life may be reduced when maintaining two connections via Multipoint


MULTIPOINT FUNCTIONALITY

To switch between the two devices, pause audio playback on the active device and start audio playback on the other connected device. It takes several seconds for the audio to switch.

Incoming calls will always take precedence over media. When a call comes in, the X8 will automatically activate the device with the incoming call. Some devices, such as computers and standalone audio transmitters, may not allow audio switching except when a phone call occurs.

If you no longer wish to connect to multiple devices, disable Bluetooth on the device you do not want connected to the X8 or disconnect the "MEE audio X8" using the Bluetooth menu of that device.

FUNCTIONALITY & CONTROLS



- You may need to bring your preferred media player application up on the screen for media playback to start.
- ** Not all devices support this functionality. For more information, refer to the user manual for your device.

SAFFTY & CARE

- To clean, remove the eartips and rinse them under running water. Clean the earphones using a cotton swab damp with a small amount of rubbing alcohol. Allow the earphones and eartips to dry completely before resuming use
- Use only the supplied Micro-USB charging cables or compatible replacements from a reputable manufacturer
- Battery performance will be severely decreased when stored in extreme temperatures: below -10°C/14°F or above 50°C/122°F, including direct sunlight
- The lifetime of the battery will be significantly reduced if your headset is not charged for a long time. It is recommended to charge your headset at least once a month.
- If the device comes in contact with liquids, quickly wipe away. If submersed in water, do not turn the device on until completely dried. Note: liquid submersion voids the warranty.
- Do not use around flammable gasses as fire may occur
- Keep the device and packaging out of reach of children

FACTORY RESET

A factory reset will clear all paired devices from the memory of the X8. To perform a factory reset, first put the headset in pairing mode as described in the Pairing with Bluetooth devices section. Once in pairing mode, press and hold all three remote buttons simultaneously for approximately 5 seconds. The red LED indicator light will flash 5 times once the memory has been cleared, and the unit will automatically enter pairing mode to be paired with a new device.


Hard Reset

To perform a hard reset, insert the charging cable and at the same time press and hold the Multifunction button until the earphone turns on. Unplug the charging cable and plug it back in to complete the reset.


Visit MEEaudio.com/Bluetooth for additional Bluetooth information and troubleshooting.

REPLACING THE CABLE

The X8 features a detachable, replaceable cable. This feature can be used to troubleshoot specific parts or to replace the Bluetooth receiver with a conventional cable.



To detach the cable, grasp the earpiece and cable connector firmly, and pull straight apart without twisting.



Re-attach the cable by lining up the grooves on the connector with the earpieces as shown. Push connectors in until they fit securely. Make sure to attach the cable connector marked "R" to the right earpiece and the connector marked "L" to the left earpiece.

Visit MEEaudio.com for replacement cables and other accessories

WARNING

Using headphones at high volumes for extended periods of time will result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety. Turn the volume all the way down after connecting your earphones, then gradually increase the volume until you reach a comfortable listening level. Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.

TROUBLESHOOTING

Visit the Bluetooth Support Page at MEEaudio.com/Bluetooth for troubleshooting procedures.

For any additional questions, visit MEEaudio.com/Support or email support@MEEaudio.com

WARRANTY

This product is covered by a 1-year manufacturer warranty when purchased from an authorized retailer. For more information, contact your local MEE audio dealer or visit MEEaudio.com/Support

HAVE A QUESTION?

Email support@MEEaudio.com

MEE audio and its logo are registered trademarks of S2E, Inc. All rights reserved.

The Bluetooth⁹ word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by MEE audio is under license. Other trademarks and tradenames are those of their respective owners.

Qualcomm aptX is a product of Qualcomm Technologies International, Ltd. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries, used with permission. aptX is a trademark of Qualcomm Technologies International, Ltd, registered in the United States and other countries, used with permission.

iPhone®, iPad®, and iPod touch® are registered trademarks of Apple Inc.



www.MEEaudio.com support@MEEaudio.com





